

RV Maintenance Logs



Item	Frequency	To Do	Notes	Suggested Products	Date Log
All			Upkeep and Issues that Arise Because of Failure to Upkeep are Not Covered Under Builders or Manufacturer's Warranty		No Log Needed
Bolts, Screws, Hardware, Ring Clamps	First 500 Miles Every 3000 Miles	Tighten as needed Tighten as needed	You are driving around a tiny house that is experiencing constant "earthquakes" Hardware, bolts, etc will loosen along the way, and may loosen sooner depending on the types of terrain and speeds.		
Plumbing	Prior to Freeze	Winterize Option to not winterize on interior - Keep van above freezing by running heater. Option to not winterize on exterior - use tank heating pad (Not all vans are built with these options)	Drain tanks, open all faucets and let run. Blow air through lines, add RV antiFreeze into tanks until it comes out of all faucets.	RV Antifreeze: https://amzn.to/3yNgvK1	
Diesel / Gas Air Heater	Prior to Running Monthly Yearly	Ensure Vans Fuel Tank has 1/4 Full or More Before Running Run on High 20 Minutes Service	Burner will fail to ignite if system is run on too low of fuel, will develop air lines in fuel line and may have to be manually primed for it to begin working. Yearly service cleans out any soot. Can be done DIY or at your local RV service center.		
Hydronic Air & Water Heaters	Prior to Running Monthly Yearly	Ensure Vans Fuel Tank has 1/4 Full or More Before Running Check Anti Freeze Fluid Levels, Fill if Needed Run on High 20 Minutes Service	Burner will fail to ignite if system is run on too low of fuel or anti-freeze, will develop air lines in fuel and heater lines and may have to be manually primed for it to begin working. Service can be done DIY or at your local RV service center. Product to use: Refill Anti Freeze with exact matching color of century heat transfer fluid for AquaHots	AquaHot Antifreeze: https://amzn.to/4c5c1g1	
AC Filter	Quarterly	Clean			
Roof Seals	Semi Annual	Check for cracking, reseal as needed	Seals are not covered by warranty and are considered standard maintenance	Lap Seal Black or White https://amzn.to/3x3GjRC Clear RV Sealant https://amzn.to/3VrwHJL	
Propane Inspect Propane	Prior to Driving Semi Annual	Keep propane off while en route Check for loose connections, tighten as needed			
Propane Detectors		Test propane detector to ensure working (push test button on detector).			
Under Carriage	Semi Annual	Look for loose plumbing connections, tighten any ring clamps or bolts, make sure all wiring is still secure			
Water Heater Sacrificial Anode Rod	Semi Annual	Remove anode and check for damage, replace if pitted.	Sacrificial anodes are designed to breakdown so your watertank maintains it's integrity. The first signs of the needing to change the anode will be leaking from the face of the water heater or the top connections.	Replacement Anode: https://amzn.to/4e6ZKti How to Remove & Replace Anode: https://youtu.be/5Ne5Jan9Cis?si=bXWUiiYF_cHwomXI	
Cleaning Exterior	Full Body-As Needed Solar Panels- As Needed	Do Not Power Wash Exterior Power will degrade as dust collects on top	May damage sensitive seals		No Log Needed
Cleaning Interior	As Needed	Wood - Wipe down with damp cloth / no chemicals Tile/Laminate - Clean with Cleaner of Choice Oiled Butcher Block -Wipe with damp cloth, Re-Oil as Needed		Butcher Block Oil: https://amzn.to/3Rd1FCC	No Log Needed